Cleaning recommendation noraplan®

1.	Initial cleaning after installation (if necessary)	Machine wet scrubbing using an active or microfibre pad or a red pad*. After vacuuming off the loose dirt with a wet vacuum cleaner scrub again with clean water and vacuum or scrub and dry. After vacuum or scrub and dry.	rub and dry.
2.	Initial polishing treatment/ polishing treatment	After the initial or intensive cleaning, evenly apply a suitable wash polish by wet mopping. The dried polishing agent film can be polished** using a suitable polishing part	an be polished** using a suitable polishing pc:
	Routine cleaning/ polishing (machine)	Optimal cleaning results are achieved with a scrubber dryer using an active or microfibre pad or a red pad* with a suitable wash polish.	
3.	Routine cleaning/ polishing (manual)	Remove dust by using suitable microfibre wipes, mop fleece or dust-binding cloths. Adhesive water-soluble or emulsifiable contaminations are removed by wet mopping.	sifiable contaminations are removed by wet
4.	Intermediate cleaning	To remove walking or heel marks and to maintain a uniform and optically appealing look of the floor covering, we recommend cleaning with suitable wash polishes using a suitable polishing pad*.	
5.	Intensive cleaning	Wet scrubbing using an active or microfibre pad or a red pad* and a suitable cleaning agent. As water-soluble polishing agents are recommended for the polishing treatment, basic cleaning agents are usually not required.	

General notes:

- As coatings (not polishes) require regular and cost-intensive basic cleaning and renewal, nora systems GmbH recommends that noraplan® rubber floor coverings, which are leakproof and have sealed surfaces, not be coated.
- Please observe the instruction in the product and safety data sheets of the cleaning & polishing agents used.
- This cleaning recommendation applies to firmly bonded floor coverings.
- In the health care sector and in laboratory areas, the initial polishing treatment by wiping is preferred, due to the media used, such as surface-, hand- and instrument disinfectants and solvents.
- * Suitable pads: 3 M etc.
- ** Use single-disc polishing machine with speeds of between 1000 1500 rpm.

Should you have any further questions please contact Inzide Commercial on 0800-800-656 to talk to a flooring professional. More detailed explanations of the cleaning procedures can be found in our document "Cleaning Definitions".

11/2021

Page 1/1

Created in cooperation with

FIGR